

# Conundrum Bracelet

## Materials needed:

- CP3023 - 17mm Copper Toggle with 26mm Bar - Qty. 1
- CP2047 - 5mm Copper Daisy Spacer - Qty. 10
- CP2007 - 7mm Copper Spacer - Qty. 8
- CP2028 - 9 x 7mm Copper Bead - Qty. 3
- 530106INDIC - 6mm Indicolite Swarovski Bicone - Qty. 6
- 530106TO - 6mm Topaz Swarovski Bicone - Qty. 4
- CBC04CP - 4mm Copper Crimp Bead Cover - Qty. 2
- SS13922 - 2 x 2mm Sterling Silver Crimp Tubes - Qty. 2
- CP170220 - 2" 20 gauge Copper Head Pins - Qty. 3
- FLX43062 - Flexrite 49 strand Bronze - Qty. 1 ft.
- DCCA51 - Cactus Bead, Tropical Oasis - Qty. 4 (2 Strands)



## Step-by-step instructions:

- 1) Using a bead stopper on the end of 1 foot of Flexrite, load the following:
  - a) Small spacer
  - b) 6mm Indicolite Swarovski bicone
  - c) Small spacer
  - d) Large spacer
  - e) Cactus bead
  - f) Large spacer
  - g) Small spacer
  - h) 6mm Indicolite Swarovski bicone
  - i) Large Copper Bead
  - j) 6mm Topaz Swarovski bicone
  - k) Small spacer
  - l) Large spacer
  - m) Cactus bead
  - n) Large spacer
  - o) Small spacer
  - p) 6mm Topaz Swarovski bicone
  - q) Large Copper Bead
- 2) Repeat with the exception of the first small spacer and the last large copper bead;
- 3) On one end, string a crimp bead and use crimping pliers to attach to the ring end of the toggle;
- 4) On the other end of the bracelet, adjust the fit and crimp to the bar end of the clasp ensuring it still fits through the ring;
- 5) Add the remaining crystals to headpins and wire wrap onto the ring side of the bracelet for a decorative embellishment.

## BeadSmith Supplies

